

BASIC SET UP FOR COMMISSIONING AN (IGT Prodigy Vu) SPEILO PICK AND PLAY

- Run cables to site controller and connect DB9 crossover to site controller and top serial port on logic box
- Insert dongle and enter into the back office with your operator key
- Set SAS address:
 - Go to:
 - Comm (main tab)
 - SAS (sub tab)
 - Under port assignment: set accounting/control to Serial 2 RS 232
 - Under port config: Serial 2 RS 232:
 - Enter SAS port number that the machine is connected to at the site controller
- Enable Games:
 - Options (main tab)
 - Games (sub tab)
 - Pay tables and denominations: choose high or low paytables and apply
- Set currency and pay out limit
 - Options (main tab)
 - Gaming machine (sub tab)
 - Set currency acceptance to \$120
 - Leave payout limit unchecked
- Other settings:
 - Calibrate touch screen:
 - Gaming machine (main tab)
 - Gaming info (sub tab)
 - Volume:
 - Options (main tab)
 - Volume (sub tab)
 - Continuous play and auto play:
 - Options (main tab)
 - Games (sub tab)
 - Play options
 - Adjust progressives:
 - Options (main tab)
 - Games (sub tab)
 - Progressives
 - Time:
 - Options (main tab)
 - Gaming machine (sub tab)
 - Date and Time
 - Serial number:
 - Options (main tab)
 - Gaming machine (sub tab)
 - Serial number